

XAP Host Software

PrimeLog+, XiLog+, basic programming and reporting

Technical Note IXD-634-TN Issue 1

The *XAP Host Software* suite provides very easy programming and readback features for PrimeLog+ and XiLog+ data loggers. Additionally, simple data graphing, reporting and export functions are incorporated. The *XAP Software* complements the *PrimeWorks*® software suite, which enables use of the full data logger features and features more extensive data processing functionality.

Functionality

- Program PrimeLog+/XiLog+
- Data readback from PrimeLog+/XiLog+
- Multiple logger programming/readback via USB batch function
- Receive SMS messages
- Download FTP data
- Graphical data display
- Tabular data reporting
- Statistics information
- Data export in .CSV format

Easy PrimeLog+, XiLog+ programming

Simply enter the following set-up details;

- Site-name
- Sensor type, calibration and engineering units
- Current meter index reading
- Logging interval
- Alarm thresholds
- Telephone number
- SMS transmission details
- FTP server details



Signal strength

Measures signal levels from available service providers.

Graphing

This module provides clear, simple to use graphing features:

- Auto-scaling
- Zoom and pan features
- Change displayed units
- Statistical information



Primayer Limited

Primayer House, Parklands Business Park
Denmead, Hampshire PO7 6XP, United Kingdom
T +44 (0)2392 252228 F +44 (0)2392 252235
E sales@primayer.com
www.primayer.com



Information in this document is subject to change without notice.